

Secure Water Treatment Testbed (SWaT): An Overview

Kaung Myat Aung
Laboratory Engineer, iTrust

Original: October 14, 2015. Updated: November 18, 2015

Table of Contents

1.0 Process and System overview.....	2
2.0 Components (sensors and actuators).....	4
3.0 Piping and instrumentation (P&ID) diagrams.....	5
4.0 Major Equipment Details	9
5.0 Control And Communication Network	15
6.0 Network Protocol.....	16



Contact: Kaung Myat Aung kaungmyat_aung@sutd.edu.sg

1.0 Process and System overview

The water purification process is composed of six sub-processes referred to as P1 through P6. Each sub-process is controlled by a set of dual PLCs, a primary and a redundant hot-standby. Operation status of the PLCs is monitored by the SCADA system.

The six processes shown in the figure are the following:

P1: RAW water Supply and storage


P2: Pre-treatment

P3: Ultrafiltration and backwash


P4: De-Chlorination System

P5: Reverse Osmosis (RO)

P6: RO Permeate Transfer, UF Backwash and Cleaning



HMI/SCADA Screenshot:



2.0 Components (sensors and actuators)

The Following picture shows the sensors and actuators associated with each PLC.

Raw Water	Pre-Treatment	Ultra-Filtration	De-Chlorination	Reverse Osmosis	RO Product
P-101 Stopped	P-201 Stopped	P-301 Stopped	P-401 Stopped	P-501 Stopped	P-601 Stopped
P-102 Stopped	P-202 Stopped	P-302 Stopped	P-402 Stopped	P-502 Stopped	P-602 Stopped
MV-101 Closed	P-203 Stopped	MV-301 Closed	P-403 Stopped	MV-501 Closed	P-603 Stopped
LIT-101 520 mm	P-204 Stopped	MV-302 Closed	P-404 Stopped	MV-502 Closed	LS-601 Normal
FIT-101 0.00 m ³ /h LL	P-205 Stopped	MV-303 Closed	UV-401 Stopped	MV-503 Closed	LS-602 HIGH
FIT-201 0.00 m ³ /h LL	P-206 Stopped	MV-304 Closed	LS-401 Normal	MV-504 Closed	LS-603 LOW
	P-207 Stopped	PSH-301 Normal	LIT-401 1008 mm H	PSL-501 Normal	FIT-601 0.00 m ³ /h LL
	P-208 Stopped	DPSH-301 Normal	FIT-401 0.00 m ³ /h LL	PSH-501 Normal	
	MV-201 Closed	LIT-301 1012 mm H	AIT-401 0.17 ppm	AIT-501 6.89	
	LS-201 Normal	FIT-301 0.00 m ³ /h	AIT-402 275.70 mV	AIT-502 204.20 mV	
	LS-202 Normal	DPIT-301 0.95 kPa LL		AIT-503 264.23 µS/cm H	
	LS-203 Normal			AIT-504 14.27 µS/cm H	
	AIT-201 142.18 µS/cm L			FIT-501 0.00 m ³ /h L	
	AIT-202 7.20 H			FIT-502 0.00 m ³ /h HH	
	AIT-203 293.59 mV L			FIT-503 0.00 m ³ /h HH	
				FIT-504 0.00 m ³ /h LL	
				PIT-501 2.64 kPa LL	
				PIT-502 0.00 kPa H	
				PIT-503 0.00 kPa	

Nomenclature of Analog Components

S/N	Symbol	Description	Engineering Unit (EU)
1	LIT	Level Indication Transmitter	mm
2	FIT	Flow Indication Transmitter	m ³ /hr
3	AIT	Analyzer Indication Transmitter i.e. Conductivity, pH, ORP	uS/cm /
4	PIT	Pressure Indication Transmitter	kPa
5	DPIT	Differential Pressure Indication Transmitter	kPa

Nomenclature of Digital Components

P for PUMP, (For Example P101 means PUMP-1 from Process Module 1)

MV for Motorised Valve

LS for Level Switch


UV for UltraViolet Module

PS for Pressure Switch (Followed by L for Low and H for High)


DPS for Differential Pressure Switch (Followed by L for Low and H for High)

3.0 Piping and instrumentation (P&ID) diagrams


P5: Reverse Osmosis Module



P6_1: RO Permeate Module



P6_2: UF backwork module



P6_3: RO/UF Cleaning Module

4.0 Major Equipment Details

Major Equipment Details For P1

Description	Design Specification	Material	Qty	Brand & Model	Remarks
Pumps & Tanks					
Raw Water Tank	Capacity: 1.8m ³ Dia xH= 1.38 x 1.36	PE	1	Rotamas CPE 1800	T101
Raw Water Transfer Pump	Duty: 2.5 m ³ /h @ 20m	Casing: Chrome Nickel SS Impeller: Noryl Shaft: SS	2	CALPEDA MXH 203	P101/102
Instrumentation					
Raw Water Tank LIT	Ultrasonic, Range 0.2 to 6m	Non Contact	1	iSOLV LevelWizard II	LIT101
Raw Water FIT	Electromagnetic DN25	PTFE	1	iSOLV EFS803/CFT183	FIT101
Piping & Accessories					
Piping	SCH80	PVC	Lot	Glywed	
Raw Water Inlet On/Off Valve	DN 25, Electric Actuated	PVC	1	Burkert EV2650	MV101
PRV	DN 25	PVC	1	Prominent DHV-DM PVC	

Major Equipment Details For P2

Description	Design Specification	Material	Qty	Brand & Model	Remarks
Pumps & Tanks					
NaCl Tank	Capacity: 250l	PE	1	Rotamas CGD 250	
NaCl/Dosing Pump	Capacity : 50 l/h @ 10 bar	Liquid end : PVDF Diaphragm : PTFE faced	2	Prominent Sigma S1Ba	P201/202
HCl Tank	Capacity: 250l Capacity: 25l (9% HCl)	PE	1	Rotamas CGD 250 25L Carboy	Double Containment
HCl/Dosing Pump	Capacity : 0.78 l/h @ 08 bar	Liquid end : Plexiglas Diaphragm : PTFE faced	2	Prominent GALa1601	P203/204
NaOCl Tank	Capacity: 250l	PE	1	CGD 250	
NaOCl/Dosing Pump (FAC)	Capacity : 0.78 l/h @ 8 bar	Liquid end : Plexiglas Diaphragm : PTFE faced	2	Prominent GALa1601	P205/206
NaOCl/Dosing Pump (UF Cleaning)	Capacity : 65l/h @ 7 bar	Liquid end : PVDF Diaphragm : PTFE faced	2	Prominent Sigma S1Ba	P207/208
Instrumentation					
Static Mixer	2" NPT M/ 12 elements	PVC	1	Omega	
Raw Water to UF Feed Tank FIT	Electromagnetic DN25	PTFE	1	iSOLV EFS803/CFT183	FIT201
AIT - Conductivity	Up to 1000µS/cm	-	1	Mettler Toledo M200 Single/ easySense Cond 71	AIT201
AIT – pH & ORP	pH: 0-14 ORP: -800mV to 800mV	-	1	Mettler Toledo M200 Dual/ easySense pH 32 & ORP 41	AIT202/203
NaCl Level Switch	Low Alarm	PVC	1	iSOLV LS880	LS201
HCl Level Switch	Low Alarm	PVC	1	iSOLV LS880	LS202
NaOCl Level Switch	Low Alarm	PVC	1	iSOLV LS880	LS203
Piping & Accessories					
Piping	SCH80	PVC	Lot	Glywed	
Raw Water Tank Outlet On/Off Valve	DN 25, Electric Actuated	PVC	1	Burkert EV2650	MV201

Major Equipment Details For P3

Description	Design Specification	Material	Qty	Brand & Model	Remarks
UF Membranes					
UF Membranes	2.5 m ³ /h	PVDF	1	TORAY HFU-2020	
Pumps & Tanks					
UF Feedwater Tank	Capacity: 1.8m ³ Dia xH= 1.38 x 1.36	PE	1	Rotamas CPE 1800	T301
UF Feedwater Pump	Duty: 2.5 m ³ /h @ 20m	Casing: Chrome Nickel SS Impeller: Noryl Shaft: SS	2	CALPEDA MXH 203	P301/302
Instrumentation					
UF Feed Water Tank LIT	Ultrasonic, Range 0.2 to 6m	Non Contact	1	iSOLV LevelWizard II	LIT301
UF Feed Water FIT	Electromagnetic DN25	PTFE	1	iSOLV EFS803/CFT183	FIT301
UF Feed Water FI	Rotameter, 1"	PVC	1	FSIV Flowmeter	FI301
Pressure Switch	Switch High/ 0-7 Bar Adjustable	SS316 Port	1	CCS 604GZ	PSH301
Differential Pressure Switch	Switch High/ 0-1 Bar	SS316 Port	1	CCS 604DZ	DPSH301
Differential Pressure Indicating Transmitter	Range: 0-2 Bar	SS316 Port	1	SPT 100 DP	DPIT301
Piping & Accessories					
Piping & Manual Valves	SCH80	PVC	Lot	Glywed	
PRV	DN 25	PVC	1	Prominent DHV-DM PVC	
Backwash On/Off Valve	DN 25, Electric Actuated	PVC	4	Burkert EV2650	MV301/2/3/4

Major Equipment Details For P4

Description	Design Specification	Material	Qty	Brand & Model	Remarks
Pumps & Tanks					
RO Feedwater Tank	Capacity: 1.8m ³ Dia xH= 1.38 x 1.36	PE	1	Rotamas CPE 1800	T401
RO Feedwater Pump	Duty: 2.5 m ³ /h @ 20m	Casing: Chrome Nickel SS Impeller: Noryl Shaft: SS	2	CALPEDA MXH 203	P401/402
NaHSO ₃ Tank	Capacity: 250l Capacity: 25l (10% NaHSO ₃)	PE	1	Rotamas CGD 250 25L Carboy	Double Containment
NaHSO ₃ Dosing Pump	Capacity : 0.78 l/h @ 8 bar	Liquid end : Plexiglas Diaphragm : PTFE faced	2	Prominent GALa1601	P403/404
UV Chlorine Destruction Unit					
UV Unit	Removal up to 0.5ppm 2.3m ³ /h	SS316	1	Aquafine Optima 200	UV401
Instrumentation					
RO Feed Water Tank LIT	Ultrasonic, Range 0.2 to 6m	Non Contact	1	iSOLV LevelWizard II	LIT401
Hardness Monitor	Range: 0-10ppm	-	1	HACH APA 6000	AIT401
AIT –ORP	ORP: -800mV to 800mV	-	1	Mettler Toledo M200 Single/ easySense ORP 41	AIT402
RO Feed FIT	Electromagnetic DN25	PTFE	1	iSOLV EFS803/CFT183	FIT401

Major Equipment Details For P5

Description	Design Specification	Material	Qty	Brand & Model	Remarks
RO Membranes					
Pre RO Cartridge Filter	Heavy Duty Multi-Cartridge Housing Max Pressure: 125PSI Number of Cartridges & Size: (4) 10" Flowrate: 28 GPM Element: 1 Micron	SS304 Housing	1	Graver 4MC1-VB-316L-1.5N-B	
RO Membrane	As Per Design Considerations	-	3+3 4	Toray TMH10A	
RO Vessel	-	Shell: Epoxy/Glass Composites	3	Pentair Codeline40S30	
Pumps					
High Pressure RO Pump With VSD	Duty: 2m ³ /h @ 5bar	Casing: Chrome Nickel SS Impeller: Noryl Shaft: SS	2	CALPEDA MXH206	P501/502
Instrumentation					
AIT – Conductivity (RO Feed)	Up to 1000µS/cm	-	1	Mettler Toledo M200 Dual/ easySense Cond 71	AIT503
AIT – Conductivity (RO Permeate)	Range: 0.02 to 20 µS/cm	-	1	easySense Cond 71	AIT504
AIT – pH & ORP (RO Feed)	pH: 0-14 ORP: -800mV to 800mV	-	1	Mettler Toledo M200 Dual/ easySense pH 32 & ORP 41	AIT501/502
Pressure Switch (Before High Pressure RO Pump)	Low Alarm, 0-10 Bar (Adjustable)	SS316 Port	1	CCS 604GZ	PSL501
Pressure Switch (After High Pressure RO Pump)	High Alarm, 0-10 Bar (Adjustable)	SS316 Port	1	CCS 604GZ	PSH501
PIT (After High Pressure RO Pump)	0-10 Bar	SS316 Port	1	iSOLV SPT 100	PIT501
PIT (RO Concentrate)	0-10 Bar	SS316 Port	1	iSOLV SPT 100	PIT503
PIT (RO Permeate)	0-10 Bar	SS316 Port	1	iSOLV SPT 100	PIT502
FIT (RO Concentrate)	Electromagnetic DN25	PTFE	1	iSOLV EFS803/CFT183	FIT503
FIT (RO Recirculation)	Electromagnetic DN25	PTFE	1	iSOLV EFS803/CFT183	FIT504

Major Equipment Details For P6


Description	Design Specification	Material	Qty	Brand & Model	Remarks
Pumps & Tanks					
RO Permeate Tank	Capacity: 1.2m ³ DiaxH = 1.16 x 1.24	PE	1	Rotamas CPE 1200	T601
RO Permeate Transfer Pump	Duty: 2.5 m ³ /h @ 20m	Casing: Chrome Nickel SS Impeller: Noryl Shaft: SS	1	CALPEDA MXP 203	P601
UF Backwash Tank	Capacity: 1.2m ³ DiaxH = 1.16 x 1.24	PE	1	Rotamas CPE 1200	T602
UF Backwash Tank Pump	Duty: 2.5 m ³ /h @ 20m	Casing: Chrome Nickel SS Impeller: Noryl Shaft: SS	1	CALPEDA MXP 203	P602
CIP Tank (UF/RO)	Capacity: 550l	PE	1	CGD 550	
CIP Pump	Duty: 2.5 m ³ /h @ 20m	Casing: Chrome Nickel SS Impeller: Noryl Shaft: SS	1	CALPEDA MXP 203	P603
Cartridge Filter					
Pre RO Cartridge Filter	Heavy Duty Multi-Cartridge Housing Max Pressure: 125PSI Number of Cartridges & Size: (4) 10" Flowrate: 28 GPM Element: 1 Micron	SS304 Housing	1	Graver 4MC1-VB-316L-1.5N-B	
Instrumentation					
RO Permeate Tank Level Switch	Low & High Alarm	PVC	1	iSOLV LS880	LS601
UF Backwash Tank Level Switch	Low & High Alarm	PVC	1	iSOLV LS880	LS602
CIP Tank Level Switch	Low & High Alarm	PVC	1	iSOLV LS880	LS603
FIT (UF Backwash)	Electromagnetic DN25	PTFE	1	iSOLV EFS800/CFT180	FIT601
FI (RO/UF Cleaning)	Rotameter, 1"	PVC	1	FSIV Flowmeter	FI601/2

5.0 Control And Communication Network

The Network Architecture for SWaT system is constructed to comply ISA-99, a security standard designed for industrial Automation and Control Systems (IACS). This standard suggests a core concept which is “Zone and Conduits” and “Layer”. It offers a level of segmentation and traffic control inside the Control and Communication Network. And It designed to support both wired and wireless network communication.

Layers

- a. Layer 3.5- De-Militarized Zone (DMZ)
- b. Layer 3- Operation Management (Historian)
- c. Layer 2- Supervisory Control (Touch Panel, Engineering Workstation, HMI Control Clients)
- d. Layer 1- Plant Control Network (PLCs) (**Star Network**)
- e. Layer 0- Process (Actuator/Sensors and Input/output modules) (**Ring Network**)



Please Note that PLC7 in above figure is just for testing/training/research

6.0 Network Protocol

[https://www.odva.org/Portals/0/Library/Publications_Numbered/PUB00123R0_Common%20Industrial_Protocol_and_Family_of_CIP_Netw.pdf]

Since we are using Rockwell Allen Bradley PLC, Main Network protocol is **CIP over EN/IP (EtherNet/IP)**. (Network Level 1)

Between PLC and Remote I/O (Network Level 0), the protocol is EN/IP.

Refer to below example of Network traffic Message and decoding: (We used tools such as Wireshark, Scapy, Ettercap etc)

Almost every second, there will be packets coming from HMI to PLC1 which look like this eg: hex-offset hex-packet (read from top-left to right-bottom)::

```
0000 80 1d 9c c8 bd e7 00 1d 9c c6 72 e8 08 00 45 00
0010 00 5e 2f 95 40 00 80 06 47 46 c0 a8 01 64 c0 a8
0020 01 0a c2 03 af 12 8e 7a 43 87 01 bd 1e 5e 50 18
0030 82 9c 2a 07 00 00 70 00 1e 00 02 00 16 00 00 00
0040 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0050 00 00 00 00 02 00 a1 00 04 00 20 42 b5 ff b1 00
0060 0a 00 8a 07 4c 03 20 b2 25 00 22 00
```

and right after, a response from PLC1 to HMI::

```
0000 80 1d 9c c6 72 e8 00 1d 9c c8 bd e7 08 00 45 00
0010 00 b8 12 13 40 00 40 06 a4 6e c0 a8 01 0a c0 a8
0020 01 64 af 12 c2 03 01 bd 1e 5e 8e 7a 43 bd 50 18
0030 20 00 e8 5f 00 00 70 00 78 00 02 00 16 00 00 00
0040 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0050 00 00 00 00 02 00 a1 00 04 00 9d 36 00 80 b1 00
0060 64 00 8a 07 cc 00 00 00 00 01 00 00 00 00 00 eb 14
0070 d3 43 01 00 01 00 01 00 02 00 0c 00 00 00 40 40
0080 00 00 80 40 00 00 80 3f 00 00 00 3f 24 00 00 48
0090 44 00 80 89 44 00 00 2f 44 00 00 7a 43 13 01 00
00a0 0b 01 00 01 0b 01 00 01 00 01 00 00 00 00 03 00
00b0 00 04 00 01 00 01 05 00 eb 14 d3 43 06 00 00 00
00c0 00 00 52 66 14 42
```

Once decoded with scapy, these packets become::

```
###[ Ethernet ]###
dst      = 00:1d:9c:c8:bd:e7
src      = 00:1d:9c:c6:72:e8
type     = 0x800
###[ IP ]###
version  = 4L
ihl      = 5L
tos      = 0x0
len      = 94
id       = 12181
flags    = 0F
frag     = 0L
ttl      = 128
proto    = tcp
chksum   = 0x4746
src       = 192.168.1.100
dst       = 192.168.1.10
\options \
###[ TCP ]###
sport    = 49667
dport    = EtherNet_IP_2
seq      = 2390377351
ack      = 29171294
dataoffs = 5L
reserved = 0L
flags    = PA
window   = 33436
chksum   = 0x2a07
urgptr   = 0
options  = []
###[ ENIP_TCP ]###
command_id= SendUnitData
length    = 30
session   = 1441794
status    = success
sender_context= 0
options   = 0
###[ ENIP_SendUnitData ]###
interface_handle= 0
timeout        = 0
count          = 2
\items \
###[ ENIP_SendUnitData_Item ]###
type_id       = conn_address
length        = 4
```



```

####[ ENIP_SendUnitData_Item ]###
type_id = conn_packet
length = 100
####[ ENIP_ConnectionPacket ]###
sequence = 1930
####[ CIP ]###
direction = response
service = Read_Tag_Service
path
status
####[ CIP_ResponseStatus ]###
reserved = 0x0
status = success
additional_size = 0x0
additional=
####[ Raw ]###
load = '\x01\x00\x00 [[ SNIPPED ]] \x14B'

```

Therefore:

- * HMI is requesting to read tag ``class 0xb2,instance 0x22`` on PLC1. In this request, the class ID never change but the instance ID may change.
- * PLC1 is responding with a successful status and a binary blob of data. This data is the concatenation of several tags, and it is only needed to find the offset where the water level is reported to be able to modify it (there is no authentication nor integrity check of the result).

As ettercap works from the TCP payload, here is this payload from another network capture, with some important values::

```

0000 70 00 ----- ENIP Send Unit Data command
02    65 00 02 00 25 00 00 00 00 00 00 00
0010 00 00 00 00 00 00 00 00 00 00 00 00
1e    02 00 ----- ENIP item count
0020 a1 00 ----- ENIP first item: Connected Address Item
22    04 00 ----- length = 4 bytes
24    db e8 00 80
28    b1 00 ----- ENIP second item: Connected Data Item
2a    51 00 ----- Size of CIP packet: 81 bytes (= 0x51)
2c    78 ed
2e    cc 00 ----- CIP response to Read Tag Service
0030 00 00 ----- CIP response status: OK
32    01 00 00 00 00 00
38    c5 8e 6d 44 ----- water level (LIT101 tag): 0x446d8ec5 = 950.23
3c    01 00 ----- Motored valve MV101 off (on is "02 00")
3e    02 00 ----- Pump P101 state: open
0040 01 00 ----- Pump P102 state: closed
42    02 00 0c 00 00 00 40 40 00 00 80 40 00 00
0050 80 3f 00 00 00 3f 22 00 00 48 44 00 80 89 44 00
0060 00 fa 43 00 00 7a 43 13 01 00 0b 02 00 01 0b 01
0070 00 01 01 01 00 00 00 00 03 00 02 00 01

```

The water level is encoded in little-endian single-precision floating-point format (IEEE 754, https://en.wikipedia.org/wiki/Single-precision_floating-point_format), so bytes ``c5 8e 6d 44`` can be decoded in a simple Python program::

program::

```

=====
import binascii, struct
print(struct.unpack('<f', binascii.unhexlify('c58e6d44'))[0])

```

which displays ``950.2307739257812``.

To find the offset of this value, it is possible to quickly scroll in Wireshark the CIP payloads of packets matching the filter ``cip.service == 0xcc && cip.class == 0xb2``, and two bytes would keep changing a lot between packets, which would be the first bytes of ``c5 8e 6d 44`` here, as they encode a part of the fraction part of the float number linked to a real sensor.

Once the offset is found, it is possible to modify the bytes in an ettercap filter, as it is done in ``mitm-b2c15-rdtag.ecf``. For example value 420 is encoded in bytes ``00 00 d2 43`` so this etterfilter code modifies the water level to 420::

More on <http://scy-phy.github.io/>